

Rescue Flash™ Signal Mirror Instructions

1. Hold mirror edges so as not to block mirror surface. Reflect sunlight from mirror onto hand or nearby surface.
2. Bring mirror close to eye, look through aiming hold at mirror's reflection. Locate bright aiming spot on grid in aiming hole.
3. Slowly move the bright spot to the target by turning and tilting the mirror.
4. Mirror will flash signal where bright spot is aimed.
5. To signal at high angles with sun close to horizon and bright spot not visible: outstretch other arm, form "V" with two fingers, sight through aiming hole with mirror reflection on V, and move V and reflection to target.

